



## XO™ Preparing for Installation Sheet

You have made a good choice by turning your vulnerabilities into security with XO™ ARMOR window films. In order to prepare for the best installation experience and the best quality, please consider the following things:

### BEFORE INSTALLATION

**INSPECT** each window to be protected, looking for scratches, nicks, stickers, and alarm components that may hinder installation. Make notes of any glass breakage and seal failure (however small) prior to installation.

**MOVE** any furniture away from the window and relocate any knick-knacks so they can not be damaged during installation. If possible, remove all window coverings.

**CLEAN** air is very important to a clean installation as airborne contaminants can get trapped in the adhesive during installation. Do your best to provide a clean, dust-free environment by closing air conditioning vents near the windows, cleaning floors the day before installation, and removing pets from the installation area(s).

### AFTER INSTALLATION

**BE PATIENT** while your new film dries. Although most XO™ films dry within a few days, drying time can be increased due to ambient temperature, film thickness, and presence of sunlight. Do not clean your windows for 30 days after installation to allow mounting adhesives to adhere properly. Do not try to “pop” bubbles and release retained water as this could void your warranty.

**CLEAN** your glass windows with a quality glass cleaner or a solution of one (1) tablespoon of liquid dish soap per quart of clean water. As with all window surfaces, use soft cloths to clean window film rather than paper towels which could scratch the surface over time.